


## Preface


This documentation is largely based off of the tutorial series '[Training Custom Object Detector - TensorFlow Object Detection API Tutorial](#)' with some additional tools and tricks. When attempting to do this if someone gets stuck they can reference the [tutorial series](#). Note that you will first need to have Cuda for GPU acceleration installed as well as Tensorflow and OpenCV installed. I have created documentation for installing [Cuda 9](#), [Tensorflow r1.12](#), and supplementary instructions for installing OpenCV 4.0.0 in supporting documentation. Note that these can also be found in the online repository

## Dataset Preprocessing

1. It's important to train at a resolution similar to that that the actual detection will be performed at. Also note that images at lower resolutions will result in training that is significantly faster. For the Final SnapCrack dataset we collected images from multiple datasets as well as a few images of our own. We resized them and then cropped them so that each image is 600x600 pixels. If adding images to the preexisting dataset it is recommended to use the 'batch\_resize.py' and 'batch\_crop.py' scripts resize and crop images respectively.
  - a. To use 'batch\_resize.py' in the terminal specify workon dl4cv and then in the terminal type 'python3 batch\_resize.py --width 600 --height 600', alternatively you can enter 'python3 batch\_resize.py -w 600 -t 600'. The resized images will be located in a new directory called 'resized'. The sample dimensions will work for a photograph with a 1:1 aspect ratio. Otherwise you will need to specify an appropriate height and width based on the aspect ratio then crop the image so that it is 600x600 pixels.




- b. To use 'batch\_crop.py' in the terminal specify workon dl4cv and then in the terminal type 'python3 batch\_crop.py --left 100 --top 0 --right 700 --bottom 600 '. Alternatively you may enter 'python3 batch\_crop.py -l 100 -t 0 -r 700 -b 600'. The cropped images will be located in a new directory called 'cropped'. This script can be use if the resized image has an aspect ratio different than 1:1




- c. After this you can label the images and add them to your final dataset

## Splitting the Dataset and Generating the tfrecord


1. The split.py script randomly splits the dataset into test and train datasets. When you run this script these datasets appear in a new image directory. Additionally there will be a version of the dataset with the data it was created in an image\_archive directory.



2. Next we will convert the xml files to csv files. Make sure the images directory and a data directory is in your current working directory then run 'python3 xml\_to\_csv.py' and the corresponding csv files for the testing and training labels will be generated in the data directory.




3. To change or add labels, this is done in the generate\_tfrecord.py script. Here we have labeled our L0, T0, and P0 for longitudinal cracks, transverse cracks, and potholes respectively. These correspond with the labeling of the final custom dataset. We need 2 tf records, one for the testing data and one for the training data. We use the respective command line arguments to generate these. 'python3 generate\_tfrecord.py --csv\_input=data/test\_labels.csv --output\_path=data/test.record --image\_dir=images/test' and 'python3 generate\_tfrecord.py --csv\_input=data/train\_labels.csv --output\_path=data/train.record --image\_dir=images/train'



```
modeste@modeste-Latitude-5480: ~/Documents/LAST_SEMESTER_CLASSES/senior_design...
File Edit View Search Terminal Help
(dl4cv) (base) modeste@modeste-Latitude-5480:~/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset$ python3 generate_tfrecord.py --csv_input=data/test_labels.csv --output_path=data/test.record --image_dir=images/test
Successfully created the TFRecords: /home/modeste/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset/data/test.record
(dl4cv) (base) modeste@modeste-Latitude-5480:~/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset$ python3 generate_tfrecord.py --csv_input=data/train_labels.csv --output_path=data/train.record --image_dir=images/train
Successfully created the TFRecords: /home/modeste/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset/data/train.record
(dl4cv) (base) modeste@modeste-Latitude-5480:~/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset$
```

## Installing the object detection API

1. Next follow installation instructions for installing the Tensorflow object\_detection API here -> [https://github.com/tensorflow/models/blob/r1.12.0/research/object\\_detection/g3doc/installation.md](https://github.com/tensorflow/models/blob/r1.12.0/research/object_detection/g3doc/installation.md) note that I used protoc version 3.4.0.
2. Next in the models-1.12.0/research directory we use command 'sudo python3 setup.py install'



```
modeste@modeste-Latitude-5480: ~/Documents/LAST_SEMESTER_CLASSES/senior_design...
File Edit View Search Terminal Help
(dl4cv) (base) modeste@modeste-Latitude-5480:~/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset/models-1.12.0/research$ sudo python3 setup.py install
[sudo] password for modeste:
```

```
Installing cythonize script to /usr/local/bin
Using /usr/local/lib/python3.6/dist-packages/Cython-0.29.15-py3.6-linux-x86_64.egg
Finished processing dependencies for object-detection==0.1
(dl4cv) (base) modeste@modeste-Latitude-5480:~/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset/models-1.12.0/research$
```

## Setting up the CNN model config file

1. Can use any of the mobilenet models. All of the [configs are located here](#). There are a number of parameters that need to be changed in the config. These include num\_classes, batch\_size... from there every "PATH\_TO\_BE\_CONFIGURED" will need to be changed. From the config for ssd\_mobilenet\_v1\_pets these config parameters include:
  - Fine\_tune\_checkpoint
  - input\_path and label\_map\_path for train\_input\_reader
  - input\_path and label\_map\_path for eval\_input\_reader
2. Note that we need to create a .pbtxt file in our training directory that corresponds to the labels in the generate\_tfrecord.py script.
3. The config file we used to train has already been downloaded and is already configured. [Models can be downloaded here](#), to download the model that we used for fine tuning in our project you can enter the following in the terminal. Once entered extract the model.
  - wget  
http://download.tensorflow.org/models/object\_detection/ssd\_mobilenet\_v1\_coco\_11\_06\_2017.tar.gz

## Training the Object Detection Model

4. Now copy the following folders into your models-1.12.0/research/object\_detection directory: data/, images/, training/, ssd\_mobilenet\_v1\_coco\_11\_06\_2017/, and ssd\_mobilenet\_v1\_pets.config. You can see more about [running training locally here](#).
5. In the models-1.12.0/research/object\_detection directory run the following command
  - python3 model\_main.py \
 --pipeline\_config\_path=ssd\_mobilenet\_v1\_pets.config \
 --model\_dir=training/ \
 --num\_train\_steps=150000 \
 --sample\_1\_of\_n\_eval\_examples=1 \
 --alsologtostderr

6. To view in tensorboard you can type the following

- `tensorboard --logtostderr --logdir=eval/`

```
(dl4cv) (base) modeste@modeste-Latitude-5480:~/Documents/LAST_SEMESTER_CLASSES/senior_design/Project/Custom_Scripts_and_Dataset/Models-1.12.0/research/object_detection$ python3 model_main.py \  
> --pipeline_config_path=ssd_mobilenet_v1_pets.config \  
> --model_dir=training/ \  
> --num_train_steps=150000 \  
> --sample_1_of_n_eval_examples=1 \  
> --alsologtostderr
```

```
Use `tf.data.Dataset.batch(..., drop_remainder=True)`.  
2020-05-06 17:26:16.281581: E tensorflow/stream_executor/cuda/cuda_driver.cc:300] failed call to cu  
Init: CUDA_ERROR_UNKNOWN: unknown error  
2020-05-06 17:26:16.281644: I tensorflow/stream_executor/cuda/cuda_diagnostics.cc:163] retrieving C  
UDA diagnostic information for host: modeste-Latitude-5480  
2020-05-06 17:26:16.281659: I tensorflow/stream_executor/cuda/cuda_diagnostics.cc:170] hostname: mo  
deste-Latitude-5480  
2020-05-06 17:26:16.281702: I tensorflow/stream_executor/cuda/cuda_diagnostics.cc:194] libcuda repo  
rtd version is: 440.59.0  
2020-05-06 17:26:16.281738: I tensorflow/stream_executor/cuda/cuda_diagnostics.cc:198] kernel repor  
td version is: 440.59.0  
2020-05-06 17:26:16.281749: I tensorflow/stream_executor/cuda/cuda_diagnostics.cc:305] kernel versi  
on seems to match DSO: 440.59.0  
creating index...  
index created!  
creating index...  
index created!  
Running per image evaluation...  
Evaluate annotation type *bbox*  
DONE (t=1.61s).  
Accumulating evaluation results...  
DONE (t=0.27s).  
Average Precision (AP) @[ IoU=0.50:0.95 | area= all | maxDets=100 ] = 0.000  
Average Precision (AP) @[ IoU=0.50 | area= all | maxDets=100 ] = 0.002  
Average Precision (AP) @[ IoU=0.75 | area= all | maxDets=100 ] = 0.000  
Average Precision (AP) @[ IoU=0.50:0.95 | area= small | maxDets=100 ] = 0.001  
Average Precision (AP) @[ IoU=0.50:0.95 | area=medium | maxDets=100 ] = 0.000  
Average Precision (AP) @[ IoU=0.50:0.95 | area= large | maxDets=100 ] = 0.001  
Average Recall (AR) @[ IoU=0.50:0.95 | area= all | maxDets= 1 ] = 0.001  
Average Recall (AR) @[ IoU=0.50:0.95 | area= all | maxDets= 10 ] = 0.009  
Average Recall (AR) @[ IoU=0.50:0.95 | area= all | maxDets=100 ] = 0.043  
Average Recall (AR) @[ IoU=0.50:0.95 | area= small | maxDets=100 ] = 0.001  
Average Recall (AR) @[ IoU=0.50:0.95 | area=medium | maxDets=100 ] = 0.019  
Average Recall (AR) @[ IoU=0.50:0.95 | area= large | maxDets=100 ] = 0.112
```

7. To evaluate a model use the following

- `python3 model_main.py \  
--run_once \  
--checkpoint_dir=training/ \  
--model_dir=eval/ \  
--pipeline_config_path=training/ssd_mobilenet_v1_pets.config`